




Disassembly instruction



A		1
	Teak wood	
B		2
	Teak wood	
C		2
	Teak wood	
D		2
	Brush bolt	

E		4
	Brush bolt	
F		16
	Steel	

STEP 1
Turn the table upside down

STEP 2
Remove the 4 short bolts on the table leg supports, 16 Screws and 2 long bolts on the table legs on the right and left sides

STEP 3
Remove table legs and table leg supports